


4. MODEL REFERENCE, LABELS AND NAMEPLATES

4.1 MODEL REFERENCE



4.2 LABELS

Label for SY01 Actuator :

WARNING
COMPRESSED SPRING INSIDE ACTUATOR

To avoid personal injury or property damage by the actuator, please follow the operating and maintenance manual and the advises below before attempting to remove or disassemble the actuator.
 Verify that pressure has been released from the actuator.
 Travel-limiting device has been disengaged.
 The spring is in the fully extended position.
 Do not tamper with factory weld components.

The ring can only
 be lifting actuator